Assembly instructions for easy joint

easy 🛭 joint

T20 and 14M version



Align the teeth. Teeth must be correctly aligned to avoid any cables damage during pin threading. Misalignment of teeth or the using of a non-chamfered pin can damage the belts cables during the installation



Cables are in contact with the pin; be careful to prevent any cables damages during the installation
Check to correctly encase the joint's teeth.




Begin to thread the pin by using an electric screwdriver and water (using as lubricant), to help the threading. For a correct alignment, use the furnished piece of belt, like photo.




When the pin is completely inserted in the belt, break the pin at the precut area.







Check that the pin doesn't exceed any edge of the belt.




Respect the indications on the belt:


ALIGN THE TEETH - CENTER THE PIN

Make the mounting easier:

system, ask for the tensioning tool for easy joint belts.









KEIPER GmbH & Co.KG - Röntgenstraße 14 - D-70736 Fellbach Fon +49 (0)711 587790 - info@keiperband.de - www.keiperband.de



Troubleshooting Guide

Problem	Possible cause	Solution
	Too high tensioning	Reduce the tension
	Incident or usury	
Joint breaking	Bad pin insertion / Misalignment of joints teeth Cable undamaged	The photo shows a case where pin was not correctly inserted (cables are not damaged). Possible cause is a misalignment of the joint teeth. Read carefully the mounting documentation, and follow the instruction: ALIGN THE TEETH CENTER THE PIN
Hard pin insertion	Absence of lubricant	Use water to help the insertion
	Misalignment of joints teeth	Align correctly the joints teeth
	No use of a chamfered pin	Use a chamfered pin, or ask for it